

T-tap Installation



Disclaimer: To ensure a solid connection when using t-taps, the wire you are tapping must be placed directly in the center of the metal jaws on the t-tap. Then, fold the t-tap and press on the sides to clamp it shut. If necessary, pliers can be used to close the t-tap. T-taps can be reused if removed in 1 piece.

