

# Raingler

## NETS & GRIPS

---

### 1992 – 2014 Ford E-Series Econoline Van Behind Front Seats Barrier Divider Net Installation

**IMPORTANT: READ INSTRUCTIONS FULLY BEFORE STARTING**

**Time:** *Approximately 20 minutes*

**Paw Level:**



**Tools:**

1. Drill and small drill bits for pilot holes
2. Panel removal tool
3. Wrenches and Torx sockets as per model year. Common for this Ford is a 14mm.

**NOTE:** if so equipped, the SRS stamp in the plastic is simply an identification marking and generally the actual SRS bags are in the overhead ceiling or in the seat themselves. Do look and verify that no plugs are unhooked, and that no wires or actual components are damaged or altered.

## Step 1

You should have the two tethers for each net with footman and D ring straps to install at the top of the B pillar/interior support beam in this manner: <https://vimeo.com/316655122>

## Step 2

Pop back the trim cover if there is one and should go to side of where this harness is:



### Step 3

The triangular anchor plates mount on B pillar on the upper seat belt bolt:

Should angle back and up so that the cap can fit back on.



### Step 4

Lower straps feed through opening on outer seat to floor bracket.



### Step 5

Feed strap ends through the attaching points and back into the net's cam buckles by squeezing the cam and inserting strap end into buckles opening. Tight top straps first and then draw out slack by tensioning lower straps. Pay attention that the seats have and retain desired range of motion. Wrap and tuck up the excess ends.

See Video [HERE](#) for details.

Thank you for purchasing Raingler Nets.  
If you have any questions please contact us,  
we are here to help!

See all our install videos on Vimeo!  
<https://vimeo.com/raingler>

**Raingler**  
NETS & GRIPS