

<u>1996 – 2002 Toyota 4Runner 3rd Gen (N180) / Hilux</u> Surf Cargo Area Ceiling Net

Supplemental Install Notes

You will see two pre-existing holes in the sheet metal that you can use to install your hardware.

On the passenger side, you will need to unscrew the existing screw and mount your hardware (driver's side does not have an existing screw). The existing tab can reinstall with our supplied footman bracket.



Thank you for purchasing Raingler Nets. If you have any questions please contact us, we are here to help!

