

Raingler

NETS & GRIPS

Behind 2nd Row Seat Barrier Divider Net Install

2001-2013 Toyota Highlander

NOTE: Many newer models have B-pillar handles and even overhead on the ceiling that can be used for some of the top mounting locations. Check to see if you prefer to use these factory locations as the nets typically have enough adjustment to allow for this option. If your vehicle does not have handles in desired locations or you prefer to install mounting points for better fitment, please follow the below steps.

IMPORTANT: READ INSTRUCTIONS FULLY BEFORE STARTING

Time: About 60-90 minutes



Paw Level:

Tools: none (may vary by vehicle)

Step 1

At inside glass edge on "C-pillar" check clearances for any hidden washer lines, wiring etc. Once position is located at corner high in bend on or above the trim plastic install mount securely to metal inner structure. (See hardware on extras page for more options)



Step 2

Remove plastic cover down in front of wheel well. Remove OEM bolt and install square ring with tab as shown. Retain plastic covers for reuse if desired later.



Raingler
NETS & GRIPS

Step 3

On floor, pop off black cover panel to check clearance and provide accessibility to install. You can mount to OEM seat belt bolt on floor or install through plastic and into when housing structure (again, checking for clearances inside before drilling) as shown.



Step 4

Install barrier straps through the mounts previously installed onto both sides, centering net and adjusting to center as desired.



Raingler
NETS & GRIPS

Step 5

Wrap any excess strap and tuck under itself to finish installation.



Check out the video here:

<https://vimeo.com/raingler>

Raingler
NETS & GRIPS

Thank you for purchasing Raingler Nets.
If you have any questions please contact us,
we are here to help!