

# 2010 - Newer Toyota Sienna Behind 2nd Row Seats Rear Barrier Divider Net Installation

NOTE: Many newer models have B-pillar handles and even overhead on the ceiling that can be used for some of the top mounting locations. Check to see if you prefer to use these factory locations as the nets typically have enough adjustment to allow for this option. If your vehicle does not have handles in desired locations or you prefer to install mounting points for better fitment, please follow the below steps.

IMPORTANT: READ INSTRUCTIONS FULLY BEFORE STARTING

**Time:** approximately 30 minutes **Paw Level:** 



#### Tools:

- 1. Ratchet or Wrench
- 2. 10MM socket/wrench
- 3. 14MM socket/wrench
- 4. Small flat blade and/or panel removal tool for removing access covers and releasing plastic snap divots.

### Step 1

Loop the top straps through the rear overhead handles, but don't fully tighten yet.

# Step 2

Install lower mounts onto the seat belt bolt behind the seat. You can slide the pointed end of the barrier nets strap through the factory seat belt lower bracket and under the existing seat belt sewn loop, or alternatively using our C1019 hardware (included with net).

See video here for full details: https://vimeo.com/316230445

## Step 3

Once all four points are connected and back into the buckles, tension the top straps first to raise the net all the way up. Then tension the lower straps to draw out the net's slack how you like the fit best, checking that the seats recline as desired.







### Step 4

Tie up the loose ends. You can do this by feeding the end of the strap through the opening of the buckle to create a loop. Feed the strap through the loop, and the strap behind, continue until no strap is hanging.

See video here for details: https://vimeo.com/316588617



Thank you for purchasing Raingler Nets. If you have any questions please contact us, we are here to help!

See all our install videos on Vimeo! https://vimeo.com/raingler

