

Raingler

NETS & GRIPS

Behind Front Seat Barrier Net Install

2015 and newer Jeep Renegade (BU)

NOTE: Many newer models have B-pillar handles and even overhead on the ceiling that can be used for some of the top mounting locations. Check to see if you prefer to use these factory locations as the nets typically have enough adjustment to allow for this option. If your vehicle does not have handles in desired locations or you prefer to install mounting points for better fitment, please follow the below steps.

IMPORTANT: READ INSTRUCTIONS FULLY BEFORE STARTING

Time: About 60 minutes



Paw Level:

Tools: (may vary by vehicle)

1. Ratchet with extension
2. Torx T-50 bit

Step 1

Slide the front seats forward for access to the outer side Torx bolt seen when looking behind towards the door opening.



Step 2

Remove Torx bolt and install the C102 black square anchor as shown:



Step 3

Tighten down oriented towards the B pillar:



Raingler
NETS & GRIPS

Step 4

Loosely hang the net up to the top 2nd row grab handles. Wrap around and back into cam buckle by squeezing the flat tab and threading the strap end through and around the handle:



Step 5

Hook the bottom straps loosely in a similar manner as the above buckles where fastened:



Step 6

Slide seats into normal riding positions and tension the net from top straps to draw it up high and the finally at the floor points:



Step 7

Finish up by tucking in the strap ends.

Check out the video here:
<https://vimeo.com/raingler>

Raingler
NETS & GRIPS

Thank you for purchasing Raingler Nets.
If you have any questions please contact us,
we are here to help!