

# 2018 – Newer Ford Expedition and 1999 – 2005 Ford Excursion Behind 2<sup>ND</sup> Row Rear Seats Barrier Divider Net Installation

NOTE: Many newer models have B-pillar handles and even overhead on the ceiling that can be used for some of the top mounting locations. Check to see if you prefer to use these factory locations as the nets typically have enough adjustment to allow for this option. If your vehicle does not have handles in desired locations or you prefer to install mounting points for better fitment, please follow the below steps.

IMPORTANT: READ INSTRUCTIONS FULLY BEFORE STARTING

Time: approximately 90 minutes

Paw Level:



### Tools:

- 1. Panel Removal Tool
- 2. Drill and bit
- 3. Wrench

**NOTE:** Move rear seats forward for easiest access.

### FOR BEHIND 2nd ROW:

### Step 1

Remove the side panel behind the 2<sup>nd</sup> row seat using a panel removal tool. Drill two holes for the provided D-ring mount in the location as shown here. Repeat on the other side.

Replace panel by snapping it back into place.

Run upper straps on barrier net through the D-ring on both sides.



## Step 2

The lower straps may either use the supplied anchor plate or attach to any bracket that is free and clear of moving mechanisms when seat lowers or raises. For more details on hardware installation, see video here: https://vimeo.com/321352161

# Step 3

Return seat positions and do final tensioning. The net can be removed, held down, or lifted as desired.





### Tie up the loose ends

You can do this by feeding the end of the strap through the opening of the buckle to create a loop. Feed the strap through the loop, and the strap behind, continue until no strap is hanging.

See video here for details: https://vimeo.com/316588617

Thank you for purchasing Raingler Nets. If you have any questions please contact us, we are here to help!

See all our install videos on Vimeo! https://vimeo.com/raingler