

Raingler

NETS & GRIPS

2021-newer Chevrolet Suburban Behind 3rd row Rear Seats Barrier Divider Net Installation

NOTE: Many newer models have B-pillar handles and even overhead on the ceiling that can be used for some of the top mounting locations. Check to see if you prefer to use these factory locations as the nets typically have enough adjustment to allow for this option. If your vehicle does not have handles in desired locations or you prefer to install mounting points for better fitment, please follow the below steps.

IMPORTANT: READ INSTRUCTIONS FULLY BEFORE STARTING

Time: approximately 20-30 minutes



Paw Level:

Tools:

1. Ratchet
2. 10mm bit

NOTE: Move rear seats forward for easiest access.

Step 1

There are some plastic hooks in the very back ceiling area with a black screw in them when you fold them open. Remove the existing bolt from the ceiling area OEM hooks.



Step 2

Reinstall bolt with provided hardware.



Raingler
NETS & GRIPS

Step 3

Once they are in place the lower straps can loosely mount to either OEM rear floor cargo hooks or to lower 3rd row seat back bracket on the sides by the plastic wall. The strap will just feed through that and back into the buckle built onto the lower corners of the net.

Step 4

Return seat positions and do final tensioning. The net can be removed, held down, or lifted as desired.

Step 5

Tie up the loose ends. You can do this by feeding the end of the strap through the opening of the buckle to create a loop. Feed the strap through the loop, and the strap behind, continue until no strap is hanging.

See video here for details:
<https://vimeo.com/316588617>

Thank you for purchasing Raingler Nets.
If you have any questions please contact us,
we are here to help!

See all our install videos on Vimeo!
<https://vimeo.com/raingler>

