

Raingler **NETS & GRIPS**

Wrap and Tuck Adjusting Strap on All Raingler Nets, Straps and Barriers

NOTE: Many newer models have B-pillar handles and even overhead on the ceiling that can be used for some of the top mounting locations. Check to see if you prefer to use these factory locations as the nets typically have enough adjustment to allow for this option. If your vehicle does not have handles in desired locations or you prefer to install mounting points for better fitment, please follow the below steps.

IMPORTANT: READ INSTRUCTIONS FULLY BEFORE STARTING

Time: About 2 minutes each strap



*Paw Level:
Tools: none*

Step 1

Install your net into position whether a stationary net like a window or barrier or loaded up as shown in this ceiling net.



Step 2

Pull adjustment straps to desired position and tuck excess into buckle. To wrap and tuck excess, feed extra strap after pulling taut, through opening in buckle.



Step 3

Pull angle end of strap from backside of buckle leaving a small opening to feed strap through "loop" on front of buckle



Raingler
NETS & GRIPS

Step 4

Tuck angle end of strap into “loop”.



Step 5

Feed and pull through “loop”.



Step 6

Continue process until all excess is wound around and through the “loop”.



Raingler
NETS & GRIPS

Step 7

Any small leftover strap on the angled end feed back into the "loop" by reversing direction and shown below. This will leave a small pull to quickly release excess and drop-down net.



Check out the video here:
<https://vimeo.com/raingler>

Raingler
NETS & GRIPS

Thank you for purchasing Raingler Nets.
If you have any questions please contact us,
we are here to help!