

Raingler

NETS & GRIPS

Install for C101 Chassis Bracket Set

Toyota Tacoma mounting point notes

IMPORTANT: READ INSTRUCTIONS FULLY BEFORE STARTING

If you do not feel comfortable performing this installation, contact most auto accessory, upholstery, off-road center or mechanic to perform the installation for a solid installation that will serve you for many years to come.

Time: 1 hour



Paw Level:

Tools:

1. Bench mounted vise
2. Drill and reamer bit. A step bit may be used or increasing diameter drill bits are alternative methods.
3. Duct tape may be used as padding to protect finish if desired.

Lower chassis brackets:

Step 1. These holes may need to be enlarged on some vehicles if the OEM bolts from the factory have a large thicker sleeve that will not fit the bracket here is what may need to be done.



Step 2. Install location



Step 3. With cover replaced. Orient bracket facing forward or to rear (shown) as desired



Optional - Rear wheel installation:



Enjoy!

Thank you for purchasing Raingler Nets

If you have any questions please contact us, we are here to help!

Tech@RAINGLER.COM or 866-905-7625