

Raingler

NETS & GRIPS

Ceiling Net Install

Jeep Renegade

NOTE: Many newer models have B-pillar handles and even overhead on the ceiling that can be used for some of the top mounting locations. Check to see if you prefer to use these factory locations as the nets typically have enough adjustment to allow for this option. If your vehicle does not have handles in desired locations or you prefer to install mounting points for better fitment, please follow the below steps.

IMPORTANT: READ INSTRUCTIONS FULLY BEFORE STARTING

Time: *About 20 minutes*



Paw Level:

Tools: *(may vary by vehicle)*

1. 5 mm allen wrench
2. Phillips screwdriver
3. Small flat blade or panel removal tool

Step 1

Carefully remove round cover from upper 1/4 panel to the rear of the small side window. Remove OE 5mm screw and replace with longer screw, square ring anchor and washer set supplied. The washer may be painted with textured undercoating paint as shown if desired.



Step 2

Install front straps to OE handles above rear seat.



Raingler
NETS & GRIPS

Step 3

Each strap has adjustability to drop down net, place soft items between net and headliner and pull straps to snug up as taut as desired, paying attention as to not put sharp edges that could dent or damage headliner. Jacket, sleeping bags, and maps secure well and can place your own carabineers to further anchor item in place.



Step 4

Tuck excess strap back into buckle opening by the push tab, wrap around through the webbing loop on top of the push tab and tuck remained inside and pack into the loop. Enjoy your ceiling net. The rear barrier net uses the same mounts just installed and can be run in conjunction with the ceilingnet. Also see our other Renegade products at raingler.com



Check out the video here:

<https://vimeo.com/raingler>

Raingler
NETS & GRIPS

Thank you for purchasing Raingler Nets.
If you have any questions please contact us,
we are here to help!