

Raingler

NETS & GRIPS

Rear Barrier Net Install

Jeep Renegade

NOTE: Many newer models have B-pillar handles and even overhead on the ceiling that can be used for some of the top mounting locations. Check to see if you prefer to use these factory locations as the nets typically have enough adjustment to allow for this option. If your vehicle does not have handles in desired locations or you prefer to install mounting points for better fitment, please follow the below steps.

IMPORTANT: READ INSTRUCTIONS FULLY BEFORE STARTING

Time: About 20 minutes



Paw Level:

Tools: (may vary by vehicle)

1. 5 mm allen wrench
2. Phillips screwdriver
3. Small flat screwdriver or panel removal tool

Step 1

Carefully remove OE round trim cover just behind the back-side window glass. Reinstall the longer supplied screws, square mount tabs and washers and tighten firmly. The washer may be painted with textured black paint to match OE trim if desired as shown.



Step 2

Hang rear barrier from top and tension until snug top mounts on both sides of vehicle.



Raingler
NETS & GRIPS

Step 3

Install middle strap on bracket catch for rear seat so that it will not become caught in the seat mechanism.



Step 4

Finally install floor mounts to OE floor hooks, tension working down and side to side. Wrap and tuck excess strap as shown.



Raingler
NETS & GRIPS

Step 5

Follow manufacturer recommendations for passenger restraint, this barrier is not an occupant safety system. See our other modular products at raingler.com.



Check out the video here:
<https://vimeo.com/raingler>

Raingler
NETS & GRIPS

Thank you for purchasing Raingler Nets.
If you have any questions please contact us,
we are here to help!