

# Raingler

## NETS & GRIPS

---

### Barrier Net Install

#### Nissan Pathfinder

**NOTE:** Many newer models have B-pillar handles and even overhead on the ceiling that can be used for some of the top mounting locations. Check to see if you prefer to use these factory locations as the nets typically have enough adjustment to allow for this option. If your vehicle does not have handles in desired locations or you prefer to install mounting points for better fitment, please follow the below steps.

**IMPORTANT:** READ INSTRUCTIONS FULLY BEFORE STARTING

**Time:** *About 10 minutes*

**Skill Level:** *2 of 5*

**Tools:** *(may vary by vehicle & only required for the upgrade)*

1. Phillips screwdriver

Thank you for your purchase! This is a dual position net and can be installed in rear behind 2nd row seats or behind front row seats with no hardware needed for a basic installation. The steps show how to replace the OEM rear install ceiling hooks (optional mounts req'd) or to move net more vertical behind rear seats get our optional C-pillar mounts. Their install is shown on our tech page [www.rainglerinstall.com](http://www.rainglerinstall.com)  
This barrier is not intended to be used with occupants in the third row seating, if so equipped.

**Step 1:** The top two mounts are OEM handle points.



**Step 2:** Loosely install the straps and orient the barrier net as shown:



**Step 3:** Tilt the front seats forward to expose the opening between the lower and back sections of the seat:



**Step 4:** Feed the lower strap from backside of seat throughout the opening towards the front lower cushion:



**Step 5:** Wrap the strap around the side of the seat and towards the rear passenger area:



**Step 6:** From rear seat area; insert end through buckle enough to hold in place and repeat for otherside.



**Step 7:** Tension from top of barrier to bottom, wrap and tuck excess after front seat positioning is completed. The barrier will restrict reclining of front seats without re-adjusting barrier straps.



**Step 8:** Rear installation (about 20 minutes) the net's orientation is reversed from that used for the front installation. Note last image below to confirm. Top strap will mount loosely to the ceiling location.



**Step 9:** You can use the OEM mount as equipped if desired for light duty applications, or replace with our steelcargo mounts as shown:



**Step 10:** Locate floor mount next to wheel well and loosely install straps.





**Step 11:** Finish side to OEM location, tighten from top to bottom and wrap excess strap and you are ready to use.



**Step 12:** Always securely tie down and fasten cargo and passengers according to OE and safety procedures.

**Enjoy!**

**Thank you for purchasing Raingler Nets**

**If you have any questions please contact us, we are here to help! [Tech@RAINGLER.COM](mailto:Tech@RAINGLER.COM) or [866-905-7625](tel:866-905-7625)**