

# Raingler

## NETS & GRIPS

---

### Side Panel Anchor Set Install

### P154 Used on RSXN Nissan Xterra

NOTE: Many newer models have B-pillar handles and even overhead on the ceiling that can be used for some of the top mounting locations. Check to see if you prefer to use these factory locations as the nets typically have enough adjustment to allow for this option. If your vehicle does not have handles in desired locations or you prefer to install mounting points for better fitment, please follow the below steps.

**IMPORTANT: READ INSTRUCTIONS FULLY BEFORE STARTING**

***Time:*** About 60 minutes



***Paw Level:***

***Tools:*** (may vary by vehicle)

1. Drill

Toggle bolt/Square ring set:



**Step 1**

Using thumbnail or small flat blade; pop and remove OEM D-rings.



## Step 2

Enlarge hole to 1/2" size opening.



## Step 3

Insert toggle bolt at angle being careful not to twist in a way as to snap nylon rods.

## Step 4

Rotate and adjust metal threaded bar to lay flat inside inner structure and align nylon rods to be equal.



### Step 5

Push flat surface trim piece evenly so that it is flush to outer plastic trim and when in position snap off excess nylon rod by pushing to sides (do this only after plastic plate is flush and taut)



### Step 6

Install bolt, square ring and washer as shown. Carefully thread for firm and tight mount. DO not over tighten.

Check out the video here:  
<https://vimeo.com/raingler>



**Raingler**  
NETS & GRIPS

Thank you for purchasing Raingler Nets.  
If you have any questions please contact us,  
we are here to help!