Raingler NETS & GRIPS

Nissan Xterra 6 point Ceiling Net RIXN Install

IMPORTANT: READ INSTRUCTIONS FULLY BEFORE STARTING

Time: About 15 minutes



Paw Level: Tools: None

IMPORTANT: If you model does not have factory ceiling hooks, they must be installed first. You will need tools and hardware as shown in the video link below. *Production products will have black coated metal hardware, not stainless color shown. See video here for details: https://vimeo.com/316655122

Step 1

Before you get started, make sure the 6 ceiling clips are facing the correct way. The 2005 and newer use metal hooks and normally do not need any repositioning. The fore and aft ceiling clips need to have their largest opening facing front to back, while the 2 center clips need to face each other as shown in the image to the right. All 6 of the attachment straps are extra-long to allow you to custom fit the net to your Xterra and cargo.

Step 2

Starting at the front or back, pass the straps through the ceiling clips. Loop them around and pass them through the buckles. Do the same for the side ceiling clips and the other end.

Step 3

The rear mounts (nearest the tailgate) should be snugged as far as they will go for proper placement of the net.

Step 4

The side mounts should be adjusted about as shown in the image here. Once your net is full with cargo, you can adjust the side mounts for tightness.



866-905-7625 | Tech@RAINGLER.com | Raingler.com









Step 5

Once all the buckles are fastened, wrap and tuck the extra strap around and through the buckles to get ends out of the way.

See video here for details: https://vimeo.com/316588617





Thank you for purchasing Raingler Nets. If you have any questions please contact us, we are here to help!

See all our install videos on Vimeo! https://vimeo.com/raingler



866-905-7625 | Tech@RAINGLER.com | Raingler.com