

Raingler

NETS & GRIPS

Nissan Xterra Behind Front Seat Barrier Net Install

IMPORTANT: READ INSTRUCTIONS FULLY BEFORE STARTING

Time: About 45 minutes



Paw Level:

Tools: 10 mm socket wrench with short extension



Step 1

(Driver's door shown) Slide front seats forward for easiest access. Lower the upper seat belt adjuster all the way down. From 2nd row seat area, loosen the weatherstripping about 12" from the front upper corner down as to allow access to plastic B pillar trim edge.

Step 2

Grasp upper portion of B pillar trim and wiggle to pop it loose enough to reach your hand inside (careful as edges inside may be sharp) and remove the black or SRS equipped pop out plastic rectangle loose pushing from back side gently. *Note: Be cautious that none of the plastic panel's removable nylon clips fall in the channel or [pick up a few extras from us when you order your barrier net.](#)



Step 3

Loosen exposed 10mm black bolt.



Raingler
NETS & GRIPS

Step 4

Fit the included Raingler C100XL hardware mount over the black 10mm bolt.



Step 5

Carefully portion the C100XL mount and the 10mm bolt to the inside mounting hole for the bolt with the tether of the D ring strap routed up and over the top of the B pillar trim panel.



Step 6

(Optional step for taller drivers). The upper seat belt adjuster can be raised all the way up and may barely contact the C100XL strap. If it is desired for free range of motion, trim a small edge off the contacting plastic.



Raingler
NETS & GRIPS

Step 7

Reinstall removable rectangle piece, snap trim nylon clips into body holes and reinstall weatherstripping while maintaining a final hardware installation with the D ring accessible as shown.



Step 8

At lower outside corner of the seat, locate and loosen the black 10mm bolt.



Step 9

Install the C102 black PVC coated square mount as shown.



Raingler
NETS & GRIPS

Step 10

Install the barrier net from the top D rings with Raingler logo oriented up. Do not tighten fully yet. Slide the seats to the normal driving positions. Install the lower straps to the C102 anchors and then tighten straps into buckles top mounts first, then lower straps. Double check that the seat position is good as well as any normal reclining ability. Do a final adjustment and tension to achieve the highest barrier height and range of seat travel.



Step 11

Once all the buckles are fastened, wrap and tuck the end straps as shown in this quick video and enjoy!

See video here for details:

<https://vimeo.com/316588617>

Thank you for purchasing Raingler Nets.
If you have any questions please contact us,
we are here to help!

See all our install videos on Vimeo!
<https://vimeo.com/raingler>

Raingler
NETS & GRIPS

866-905-7625 | Tech@RAINGLER.com | Raingler.com