

Raingler

NETS & GRIPS

Barrier Net Install

Toyota Tundra 2003 and newer

NOTE: Many newer models have B-pillar handles and even overhead on the ceiling that can be used for some of the top mounting locations. Check to see if you prefer to use these factory locations as the nets typically have enough adjustment to allow for this option. If your vehicle does not have handles in desired locations or you prefer to install mounting points for better fitment, please follow the below steps.

IMPORTANT: READ INSTRUCTIONS FULLY BEFORE STARTING

Time: *About 45-60 minutes*



Paw Level:

Tools: *(may vary by vehicle)*

1. Drill and small drill bit for pilot holes (pre-drilling) mounting footman screws
2. Panel removal tool
3. Wrenches and Torx sockets as per vehicle's need

Here is the finished anchor point for the top mount strap installed correctly in place



NOTE: the SRS stamp in the plastic is simply an identification marking and generally the actual SRS bags are in the overhead ceiling or in the seat themselves. Do look and verify that no plugs are unhooked, wires or actual components are damaged or altered.

Raingler
NETS & GRIPS

866-905-7625 | Tech@RAINGLER.com | Raingler.com

Step 1

This step is done similarly in most vehicles by loosening the upper part of the trim panel. Some vehicles this can be done by simply popping the trim snaps loose and carefully pulling out. Other vehicles may have a two-piece trim panel that requires the lower piece removed first as shown.

Frist photo is of a Toyota



Second Photo is of a Ram



Raingler
NETS & GRIPS

866-905-7625 | Tech@RAINGLER.com | Raingler.com

Be sure to look for fasteners in handle cover pop-outs and upper seat belt anchor bolts like the Torx bolt

Step 2

Remove upper trim panel enough for access to the inner metal structure near the headliner



Step 3

Mount the footman strap by locating a good open metal surface as to not be too low to push down on the re-assembled plastic trim and not too high to interfere with the headliner material. Mark location on holes and pre-drill the mounting screws again being careful to check that no lines, wiring or seat belt interference will occur when re-assembled.

Picture of a Toyota



Picture of a Ram

Raingler
NETS & GRIPS

Ford F250 Supercab using OE Torx bolt location



Toyota FJ using Torx bolt:



Raingler
NETS & GRIPS

866-905-7625 | Tech@RAINGLER.com | Raingler.com

Step 4

Reassemble and final check that there are no obstructions to upper seat belt adjustment or trim panel fasteners etc.

FJ Cruiser:



Ford F250:



Raingler
NETS & GRIPS

866-905-7625 | Tech@RAINGLER.com | Raingler.com

Step 5

Many trucks will have the lower straps either attach to factory seat brackets to the bottom of the seat. Do check that where the strap is install is not an abrasive sharp edge (We offer flat hooks on our hardware section, but generally a simple relocation of the strap will do.)

* Other trucks will use a lower mounting bracket mounted to the lower seat belt bolt or the seat to floor bolt.



*Install and re-assemble with lower mount in place



Raingler
NETS & GRIPS

866-905-7625 | Tech@RAINGLER.com | Raingler.com

Step 6

Tension from top first, working your way to the floor. Pay attention to adjusting for normal seat positioning, wrap and tie off the excess adjusting straps. NOTE: A video is on our YouTube or install page showing how to finish off end strap neatly if desired.



Check out the video here:
<https://vimeo.com/raingler>

Raingler
NETS & GRIPS

Thank you for purchasing Raingler Nets.
If you have any questions please contact us,
we are here to help!

866-905-7625 | Tech@RAINGLER.com | Raingler.com