

# Raingler

## NETS & GRIPS

---

### Barrier Net Install

### 2002-2007 Jeep Liberty

NOTE: Many newer models have B-pillar handles and even overhead on the ceiling that can be used for some of the top mounting locations. Check to see if you prefer to use these factory locations as the nets typically have enough adjustment to allow for this option. If your vehicle does not have handles in desired locations or you prefer to install mounting points for better fitment, please follow the below steps.

IMPORTANT: READ INSTRUCTIONS FULLY BEFORE STARTING

**Time:** 30-45 Minutes



**Paw Level:**

**Tools:**

1. 10mm socket and power driver or ratcheting wrench
2. 16mm wrench
3. Trim or panel removing tool

### Step 1

Pull back pillar trim behind rear seat.

### Step 2

Install footman mount in area close to the headliner on the pillar. Watch out for wires and be sure that there is nothing behind where you are drilling. You can also cut away a bit of the headliner or the panel piece to allow less pressure on the panel piece when tightening. Our updated units now have the C100M D ring strap kit so that trimming is not necessary. Just feed the extension strap over the top of the trim and below the headliner material. Repeat for each side.

### Step 3

Run the upper straps through the footman mount on each side.



**Raingler**  
NETS & GRIPS

#### Step 4

Run center strap on each side through the seat bracket as shown.



#### Step 5

Run bottom straps through factory OEM floor mounts in cargo area.



**Raingler**  
NETS & GRIPS

## Step 6

Tighten straps all the way around, and wrap and tuck them for a nice, clean look.



Check out the video here:

<https://vimeo.com/raingler>

**Raingler**  
NETS & GRIPS

Thank you for purchasing Raingler Nets.  
If you have any questions please contact us,  
we are here to help!