

Raingler

NETS & GRIPS

Ceiling Storage Net-Rear Area

2010-newer Subaru Outback

NOTE: Many newer models have B-pillar handles and even overhead on the ceiling that can be used for some of the top mounting locations. Check to see if you prefer to use these factory locations as the nets typically have enough adjustment to allow for this option. If your vehicle does not have handles in desired locations or you prefer to install mounting points for better fitment, please follow the below steps.

IMPORTANT: READ INSTRUCTIONS FULLY BEFORE STARTING

Time: 30 - 90 minutes



Paw Level:

Tools:

1. 10mm socket and power driver or ratcheting wrench
2. 16mm wrench
3. Trim or panel removing tool

Safety note: Secure any items that could shift and fly forward in a sudden stop with carabineers or similar attaching devices.

C pillar installation

Step 1

Carefully pop off the rear shoulder seat belt bolt cover cap.
Driver's side shown.



Step 2

Remove 16mm bolt holding the upper seat belt slider.



Raingler
NETS & GRIPS

Step 3

Carefully grasp and pop the top trim cover piece back. It is sometimes helpful to loosen just a bit of the top rubber door surround to make pulling the trim loose a bit easier. Notice the 10 mm bolt on the silver bracket here for next step.



Step 4

Remove the 10mm bolt.



Step 5

Align the above removed 10mm bolt to the supplied hardware as shown.



Step 6

Install the hardware d-ring strap with the square ring down and the mount tab, washer and bolt on the top. (the rubber side of the washer faces the mount tab). The D-ring will be extended out and over the top of the reassembled trim panel.



Step 7

Reinstall the plastic trim piece and any rubber door surroundings loosened earlier with the D-ring going over the top of the trim piece.



Step 8

Install the chassis bracket oriented to the rear with the cap cover as it was positioned originally.



Raingler
NETS & GRIPS

D pillar and rear overhead mount install

Many models will have factory (OEM) ceiling anchors that can be used quickly and securely. If you are unable to use these, you may perform the alternative installation below.

Step 1

Remove pop off plastic cover if in place to expose the OEM hook.



Step 2

Feed the strap end through the opening from over to below.



Raingler
NETS & GRIPS

Finish the install as required for your ceiling net, position to not obstruct any lights or factory



Alternative rear ceiling mounts:
(Requires minor mount drilling in hidden area)

Step 1

At D pillar, pop off upper portion of plastic trim piece. Note any lines or wiring that needs to be avoided.

Step 2

Install the D ring strap with the two mount screws.

IMPORTANT: Watch all clearances as to not puncture and sheet metal or lift gate surrounds.

Measure and look twice to only drill once applies here.

Predrill your mounting holes and orient so that the D ring strap will be finished over the top of the interior trim panel and facing towards the center of the cargo area.

Step 3

Reinstall the trim panel and attach the rear straps to the storage net.

Step 4

Do final positioning

Check out the video here:
<https://vimeo.com/raingler>



Thank you for purchasing Raingler Nets.
If you have any questions please contact us,
we are here to help!