

# SCREENS BY **CORE**<sup>®</sup>

## How to Install

### Step 1



First, attach the 4 adjustable feet to the base of your planter.

### Step 2



Next, attach the left and right brackets to the rear of your planter using the fixings provided.

### Step 3



Now attach the left and right hanging mechanism to your metal screen.

Please note, the hanging mechanism is designed to sit behind the design to hide them from sight, but they're shown exposed here for illustration purposes.

### Step 4



You now need to carefully slot your metal screen into position within the brackets on the planter. Ensure you lower both sides evenly.

Please turn over for further steps

# SCREENS BY **CORE**<sup>®</sup>

## How to Install

Step 5



Step 6



Step 7



Step 8



Now bring your planting screen unit into place, against your supporting wall or surface. Use a marker pen to draw a dot within the top section of the hanging mechanism, as shown here.

You now need to move your planting screen unit out of the way.

1. Drill a hole through the dot
2. Insert your rawplug if it's a brick/concrete wall (not required for wood)
3. Insert your fixing. Leave the fixing 5mm away from the wall

Next, bring your planter and screen back into position and carefully lower your screen into the brackets, whilst also hooking your hanging mechanism onto the wall fixing.

*Voila!*

Now all that is left to do is to get your hands dirty filling the planter with beautiful plants!