



Crawford Performance Overland Series  
Hood Light Pod Bracket  
2019+ Forester

**B2271-1 Parts List**

Part Number	Quantity	Description
B2271	2	Bracket – Hood Light Pod Mounting Bracket



## Crawford Performance

### Tools Needed:

3/8" Ratchet

12 MM Socket



**Estimated Install Time:** 1 Hour

**Install Difficulty:** 1/10

## Installation Instructions

1. Open the hood of your vehicle and locate the hood mounting brackets near the left and right edges of the hood closest to the windshield.



2. Remove lower hood bracket nut on one side of the vehicle (12 MM socket, 3/8" nut driver). **Perform this on one side at a time to avoid misaligning the hood.**





## Crawford Performance

3. Align light pod bracket with hood mount bracket. Fasten to hood with Factory 12 MM nut removed in previous step. The hood bracket nut closest to front of vehicle does not require removal, the light bracket uses this nut to align properly on vehicle.



4. Make sure bracket is tightly fastened to the hood. Repeat for the opposite side of the vehicle, making sure to only remove specified fastening hardware.



## Crawford Performance

5. Complete set up with desired light pod and wiring set up. Make sure bracket is secured to vehicle.



**Thank you for choosing Crawford Performance!**

**Please feel free to contact us for any questions or comments! We are here to help. We understand this is a difficult install and we commend you for your efforts. Celebrate by cracking a beer and pouring one out for your chewed-up arms.**

**2319 E Locust Ct. Suite A  
Ontario, California 91761**

**[Technical@crawfordperformance.com](mailto:Technical@crawfordperformance.com)**

**(855) 677-8243**

