



## **DV8 Offroad**

### **DV8 Offroad Slider Installation Instructions**

Congratulations on the purchase of your DV8 Offroad rock sliders. DV8 Offroad Rock Sliders are built Jeep tough and will provide you with exceptional style and rugged durability for years to come.

#### Installation Instructions:

1. Remove the side rails from their original packaging and separate the right from the left.
2. Before removing factory bolts, hold the side rails in position under the vehicle in the desired position and locate the mounting points under the Jeep. The side rails will mount to the Jeep in same location that the body is bolted to the frame of the vehicle.
3. At the mounting surface, there will be on large bolt and a smaller bolt on either side. Remove the two smaller bolts and place in a secure location. These bolts will be reused in mounting the side rails. Repeat on second mounting location.
4. Lift the rock slider into position. The rock slider mounting surface will fit around the large body bolt and be secured by the two bolts that were removed in step 3.
5. Reinstall the bolts removed from the Jeep mounting points loosely to secure the rock slider in place. Do not tighten until the rock slider is secured by all four bolts.
6. Position the rock slider in the desired location with the loose bolts. Make sure that the rock slider is not resting against the body of the Jeep. Tighten the bolts down with the rock slider in the desired location.
7. Repeat steps 2 through 6 for installing the second rock slider.
8. Re Torque all factory bolts before completing install.

Enjoy and thank you again for choosing DV8 Offroad products.