

## MOBILE STORAGE SYSTEMS

STRENGTH BY DESIGN SINCE 1999

WHAT YOUR KIT INCLUDES:

I X REAR WINDOW GUARD LHS
I X REAR WINDOW GUARD RHS

I PERSON INSTALLATION



## INSTALLATION TIME APPROXIMATELY 30 MINS

## REAR WINDOW GUARDS FITTING INSTRUCTIONS

PLEASE READ THROUGH FULLY BEFORE ATTEMPTING INSTALLATION.
ANY QUESTIONS, PLEASE CONTACT US.

- I. USE THE CORRECT SIDED GUARD FOR YOUR WINDOW. THE GUARD SHOULD FOLLOW THE SHAPE OF THE WINDOW WITH THE GUARD ALMOST AGAINST THE GLASS
- 2. REMOVE TRIM PANELS, IF FITTED.
- 3 LOOSEN THE BOLTS THAT SECURE THE ROOF TO THE BACK PANEL. YOU WILL NEED A 10MM SPANNER OR SOCKET FOR THIS.
- 4. PUT THE GUARD IN PLACE PUSHING THE TOP SLOTS OVER THE BOLTS. TIGHTEN THE BOLTS ENSURING THAT THE GUARD IS AGAINST THE WINDOW RUBBER.
- 5. PUSH THE BOTTOM OF THE GUARD AGAINST THE WINDOW AND DRILL FIXING HOLES THROUGH INTO THE BOTTOM FLANGE. USING THE HOLES IN THE GUARD AS GUIDELINES. USE AN APPROPRIATE SIZE DRILL BIT TO HOW YOU WISH TO FIXING PREFERENCE. IE SELF TAPPING SCREW, POP RIVET, NUT AND BOLT ETC.
- 6. REPLACE ANY TRIM PANELS YOU MAY HAVE REMOVED IN STEP 2.



THESE INSTRUCTIONS CAN BE VIEWED ON OUR WEBSITE