



MOBILE STORAGE SYSTEMS

STRENGTH BY DESIGN SINCE 1999

WHAT YOUR KIT INCLUDES:

1 X CHEST UNIT
2 X M8 X 50 SET SCREWS
4 X M8 X 35 SET SCREWS
6 X M8 REPAIR WASHERS
6 X M8 SHAKEPROOF WASHERS

WHAT YOU WILL NEED:

1 X 13MM SPANNER/SOCKET
1 X DRILL & DRILL BITS
1 PERSON INSTALLATION



INSTALLATION TIME APPROXIMATELY 60 MINS

STORAGE CHEST FITTING INSTRUCTIONS

SUITABLE FOR STANDARD; SLIMLINE (ALL MODELS); MINI & MICRO CHEST

*PLEASE READ THROUGH FULLY BEFORE ATTEMPTING INSTALLATION.
ANY QUESTIONS, PLEASE CONTACT US.*

1. BEFORE YOU INSTALL THE CHEST YOU NEED TO CREATE A DRILLING TEMPLATE. USING THE BOX THAT YOUR DRAWER WAS DELIVERED IN. SIMPLY PLACE YOUR CHEST ON THE CARDBOARD AND CUT AROUND IT ACCURATELY. MARK THE HOLES YOU WILL NEED TO DRILL BY USING A PENCIL THROUGH THE HEXSERTS SITUATED ON THE SIDES.
2. PLACE TEMPLATE IN THE LOCATION THAT YOU WOULD LIKE TO INSTALL THE STORAGE CHEST. IF YOU ARE INSTALLING BETWEEN THE WHEELARCHES OF A LAND ROVER DEFENDER PLEASE ENSURE THAT THE CHEST IS PLACED CENTRALLY BETWEEN THE WHEELARCHES. 'CENTRE DOT' ONE OF THE HOLES IN THE TEMPLATE. REMOVE THE TEMPLATE AND DRILL A SMALL PILOT HOLE. **TIP: CHECK UNDER THE VEHICLE THAT IT IS CLEAR BEFORE YOU DRILL.** IF THE POSITION IS OK, USE THE DRILL BIT TO RE-LOCATE THE TEMPLATE INTO POSITION AND DRILL THE REMAINING HOLES.
- 2b. IF YOU ARE INSTALLING A STORAGE CHEST ALONGSIDE A DRAWER UNIT PLEASE MAKE SURE YOU INSTALL THE CHEST FIRST.
3. THEN REMOVE THE TEMPLATE AND DRILL OUT THE HOLES TO 10MM.
4. CAREFULLY PLACE YOUR STORAGE CHEST IN THE REAR OF YOUR VEHICLE. **TIP: IF INSTALLING A MINI CHEST OR STANDARD STORE CHEST, TO PROTECT THE UNIT, YOUR VEHICLE AND YOURSELF WE RECOMMEND TWO PEOPLE LIFT THE CHEST UNIT INTO THE VEHICLE.**
5. FROM UNDERNEATH THE VEHICLE PLACE A M8 SHAKEPROOF WASHER AND ONE M8 REPAIR WASHER ON AN M8 BOLT AND START TIGHTENING IT INTO THE HEXSERTS INSTALLED INTO THE BASE OF THE CHEST UNIT. START ALL BOLTS OFF LOOSELY AND WHEN ALL ARE IN PLACE TIGHTEN TO 25LBS/FT.