

Mitsubishi Evolution X/Ralliart JDC Bumper Quick Release Installation Instructions

If you are not comfortable drilling permanent holes in your bumper please ask a professional for help. JD Customs U.S.A. is not responsible for any damages made during the install or use of this product.

Step 1: Installation can be done without removing the entire bumper if you do one side at a time. Remove the plastic tabs inside the fender on either left or right side.

Step 2: Remove the 10mm bolt that holds the bumper to the fender. You should see a black plastic brace like in the picture below.



Step 3: Remove the 10mm bolts that hold the brace in place and pinch the black tabs from behind to remove the brace.

Step 4: Install the bracket as shown in the picture below using the hex head bolts with lock nut and washers.



Mitsubishi Evolution X/Ralliart JDC Bumper Quick Release Installation Instructions

Step 5: Use a marker or paint to leave a small amount on the tip of each ball pin. Line the bumper up to where it would normally sit and press it into the ball pins to leave a mark on the back side of the bumper.

Step 6: Drill a 3/4" hole for each latch where the mark was left on the bumper.

Step 7: Insert the quick release button into the hole and secure it from the opposite side with the provided nut.

Step 8: Press the latches into the ball pin(s) until they snap into place and check the alignment. If necessary, adjust the ball pin(s) to make the bumper flush with the fender.

Your finished installation should look similar to the picture below.



Please upload a picture and tag us! We love to see our products in action! Also make sure to tell your friends where to purchase their Evo X Bumper Quick Release Kit! We appreciate your business.



**Don't forget to
leave a review
and follow us!**

Call/Text (423) 665-9616

www.Jdcustomsusa.com

Instagram: JD_Customs_USA

Facebook: Jdcustomsusa