



APOC NOTES:

1. IN COLD WEATHER, PRE-HEAT BACK SIDE OF PRO-TACK.
2. ON GRAVEL SURFACES, SPUD AREA BEING REPAIRED.
3. FOLLOW APOC - ARMORFLEX ROOF RESTORATION SPECIFICATION GUIDELINES.
4. FOLLOW APOC MATERIAL PREPARATION AND APPLICATION RATES, INCLUDING ARMORFLEX #525 SURFACING COMPOUND AND APPROVED TOP SURFACING OPTIONS.
5. PRIME ALL REPAIR SURFACES WITH APOC #103 PRIMER PRIOR TO NEW MEMBRANE INSTALLATION.

REPLACEMENT OF WET INSULATION AND DAMAGED
MEMBRANE

ARM-10

NOT DRAWN TO SCALE