



NOTES:

1. REMOVE METAL PARAPET CAP, INSTALL PRO-TACK, AND REINSTALL METAL.
2. SPUD AND REMOVE ALL GRAVEL WITHIN 2-INCHES OF PRO-TACK.

<p>METAL PARAPET CAP (COPING) AND BASE FLASHING</p>	<p>ARM-1</p> <p>NOT DRAWN TO SCALE</p>
---	--