

Horizontal Flashing Flange
(Prime both sides of horizontal
flange and set in bed of
Cement on Finished
Roof Plies. Stagger Nail to Deck
or Wood Blocking at 3" O.C.)

