

| APOC REPAIR REFERENCE GUIDE | | | |
|-----------------------------|-------------------|--------------------------------|--|
| BUR | DEFECT | REPAIR MASTIC or SEALANT | REINFORCEMENT |
| 1 | Splitting | 115, 365, 264 or 515 | Pro-Tack or Incredible Fleece Top Tape |
| 2 | Blisters | 136 or 525 | Plies equal to existing |
| 3 | Ridges & Wrinkles | 115, 365, 264 or 515 | 483 Polyester |
| 4 | Flashing | 115, 365, 264 or 515 | 483, Pro-Tack or Fleece Top Tape |
| MOD-BIT | DEFECT | REPAIR MASTIC or SEALANT | REINFORCEMENT |
| 1 | Laps & Seams | 115, 365, 136, 525 or 515 | 483 Polyester |
| 2 | Blisters | 115, 365, 264, 136, 525 or 515 | Plies equal to existing |
| 3 | Flashing | 115, 365, 264, 136, 525 or 515 | 483, Pro-Tack or Fleece Top Tape |
| SINGLE-PLY | DEFECT | REPAIR MASTIC or SEALANT | REINFORCEMENT |
| 1 | Laps & Seams | 515, 5800 | 483 Polyester or Fleece Top Tape |
| 2 | Punctures & Tears | 515, 5800 | Fleece Top Tape |
| 3 | Flashing | 515, 585, 252 or 545 | 483 |
| 4 | Shrinkage | CUT & SPLICE ✂ | CUT & SPLICE ✂ |
| METAL | DEFECT | REPAIR MASTIC or SEALANT | REINFORCEMENT |
| 1 | Exposed Fasteners | 515, 5800 or 264 | None |
| 2 | Horizontal Seams | Injected 515 | Fleece Top Tape |
| 3 | Flashing | 264, 515 or 5800 | 483 or Fleece Top Tape |
| 4 | Vertical Seams | 264, 515 or 5800 | 483 or Fleece Top Tape |

4 REPAIR TIPS

1. Substrate must be clean and dry.
2. Where applicable, use appropriate primer.
3. Repair leaks and defects with mastics and reinforcements (coatings alone do not qualify as a waterproofing membrane).
4. All repairs must be coated or granulated to match existing roof.

For technical support and specs contact your local APOC representative.