

- 1 Stowage rail contruction
 - Drill out five pilot holes on each side of turret on each side of turret.
 - Insert cut lengths of pewter rod to protrude approximately 5mm from hull.
 - Use length of pewter rod in set. Bend ends to fit into first and last pilot holes.



• Trim rod in hull to connect to inner portion if Stowage rail

