



1 Stowage rail construction

- Drill out five pilot holes on each side of turret on each side of turret.
- Insert cut lengths of pewter rod to protrude approximately 5mm from hull.
- Use length of pewter rod in set. Bend ends to fit into first and last pilot holes.



- Trim rod in hull to connect to inner portion of Stowage rail

