

stickeredup4lemans

Sun Strip Application Instructions



mark the centre-point of the windscreen



spray the windscreen with a fine mist of water mixed with a couple of drops of fairy liquid



carefully remove the sticker from the backing



spray the sticky side of the sticker with the same



lay the sticker on the windscreen and line the tiny notch, at the top of the sticker, up with the



carefully squeegee out the excess water and push the sticker into the edge of the windscreen



using a sharp blade, very carefully trim away the excess material by running the blade around the windscreen trim



pull away the excess material leaving the sunstrip in place. allow to dry for 12 hours before driving at speed



StickeredUp4LeMans and Stickers4 are trading names of HolloGraphics Ltd +44(0)1962 882345 hello@stickeredup4lemans.com

www.StickeredUp4LeMans.com