

## Viper Stripe Application Instructions.

Please read these instructions carefully before you attempt to apply your stripes.

- ⊗ These stripes have been manufactured from vehicle grade vinyl and are perfectly safe for your vehicle. However, we would ask you to read our terms and conditions for the use and application of vehicle graphics at [www.hollographics.com/info/terms.html](http://www.hollographics.com/info/terms.html) - Thank you.
- ⊗ Prepare the surface. Application surface must be totally clean of wax, oil and grease.
- ⊗ With the stripe still on the backing, position it as a test fit to get an idea of lengths required for each panel. Be careful not to stretch the vinyl. It is a good idea to mark the inside and outside edges of where the stripes are going with masking tape or a china-graph pencil.
- ⊗ Using a household water spray bottle prepare a solution using 4-5 drops of dish washing liquid to one pint of water. Do not add too much washing liquid as this will prevent proper adhesion.
- ⊗ With the help of an assistant carefully remove the backing sheet to expose the adhesive. Spray the back of the exposed striping and the application surface thoroughly with the water spray. Line up the strip and lay it on to the vehicle panel.
- ⊗ Take a step back to eye up the alignment. Re-position as necessary using measurements from the reference points of the vehicle. (i.e. The cars logo or washer jets.)
- ⊗ Once properly aligned, go over the entire stripe with a soft cloth or squeegee to ensure bond and that no air bubbles are present. Try and squeeze out as much of the water as possible.
- ⊗ If possible, leave your car in a dry location and try not to drive the car for at least 24 hours to allow time for all the water to evaporate and the adhesive to dry.
- ⊗ Check your work the next day. If you find air bubbles, pierce them with a pin and gently work the air out with your squeegee.
- ⊗ Do not wash your car for at least 72 hours.

