

Honda CB500 X/F & NC700X Mirror Extenders Installation Instructions



Provided

2 Custom, black anodized aluminum screws

Left Extender (engraved)

Right Extender

From your garage

14 mm open wrench

6 mm Allen (hex) wrench *

** provided with Revision*

w6mmAW

- 1) Slide the rubber cap up to expose the screw on the mirror as shown



- 2) Using a 14 mm open wrench, unscrew the **lower nut** of the mirror with a **counterclockwise** motion.

- 3) Screw the mirror to the mirror extender's threaded hole as shown



- 4) Use the **6 mm Allen wrench** to screw the mirror extender to the handle bar with the black custom hex screw provided.



Now, use the 14 mm open wrench to tighten the **lower nut** of the mirror with a **clockwise** motion.

- 5) To adjust the mirror's position, use the 14 mm open wrench **to loosen up** the **upper nut** of the mirror with a **clockwise** motion.

Adjust the mirror's position to your liking and **tighten** the **upper nut** with a **counterclockwise** motion.



6) Repeat these steps for the other mirror

