

Kawasaki Versys 1000LT Flatfoot for Lowering Kit Installation Instructions



What you will need to shorten the kickstand

- Masking tape
- Hack saw or a friction saw
- File for breaking sharp corners

Note: If you decide to remove the kickstand for cutting it, you will need additional tools.

You will need help to securely hold the bike while you are cutting the kickstand and installing the insert.



Wrap the masking tape around the kickstand so the bottom of the tape is **3 and 3/8 inches (85 mm) measuring from the bottom of the spring grip peg down**, just as shown in the photo.

Now, **cut along the bottom edge of the tape** (without cutting the tape). Make the cut square to the kickstand.

Then, file off the sharp edge of the shortened kickstand's end, so the peg can slide easily into place.

Assemble the flatfoot by attaching the bottom plate to the peg with the 2 Phillips screws provided and **use Loctite Threadlocker No 242 Blue®** with the Phillips screws. Then, slide the flatfoot onto the shortened kickstand and twist it back and forth so that plate is flat to the ground. Please tighten the 2 side screws on the foot peg with the **4 mm Allen hex wrench**.