

2015 Kawasaki Versys 650 Passenger / Rear Lowering Foot Pegs Blocks Installation Instructions

Thank you for purchasing our Passenger Lowering Foot Pegs Blocks!

Items included



Left Block



Right Block



Two M-6 Screws



Two M-6
Locknuts

Tools needed for installation



From your garage toolbox (from left to right):

- Small flat screwdriver
- Open wrench 10 mm or adjustable wrench

From your Kawasaki Versys toolkit:

- Open wrench 10 mm / 12 mm

Additional preparation note

- **Please prepare the assembly area so that it is free of clutter, so if you drop the snap ring or the locking ball bearings, you can easily find them!!!**

Installation Instructions

- 1) Wedge the C-shaped retaining ring out with the small flat screwdriver and remove the pin holding the rear foot peg to the bike.
- 2) Get the **Lowering Block** and hold it in your hand. With the other hand, slide the foot peg together with its snap mechanism and the plastic washer out of the steel U-shaped bracket, as shown:



Please make sure **to hold and compress** everything together firmly, so the ball bearings and springs from the snap mechanism do not pop out while you do it!

- 3) Slide the whole foot peg mechanism into the Lowering Block and reinstall the pin



- 4) Reinstall the retaining ring and snap it back in its place as shown with the screwdriver



- 5) Slide the Foot Peg Block back in and insert the provide M-6 screw. Then, attach the M-6 Locknut and screw both with a 10 mm wrench.



- 6) Tighten both the M-6 Screw and the M-6 Locknut so that there is no slap, as shown



Tighten the **M-6 Screw and Locknut** with the 10 mm open wrench at medium strength, or if you have a torque wrench then tighten it at 25 N/m (2.5 kgf/m), (18 ft/lb)

7) Please repeat steps 1 through 6 to install the other Lowering Block

