

2015 Kawasaki Versys 650 Standard Flatfoot Assembly Instructions

Standard Flatfoot Components



PARTS: bottom plate, top plate, a spring,
and 4 screws



Fully Assembled

Tool needed for installation

- **From your garage toolbox:** Phillips Screwdriver

Assembly Instructions

- 1) Slip the foot of the original kickstand through the top plate as shown in the photo, and make sure that the pointy side of the top plate faces to the outside of the bike.



2) Swing the kickstand to the up position.

3) Place the spring in between the seat of the top plate and the original foot of the kickstand.



4) Insert the original kickstand foot into the cutout of the bottom plate as shown in the photo, and compress all four together. Make sure that the top plate is aligned with the bottom plate in such a way that their pointy sides face the same way to the outside of the bike.



Pointy sides of the top and bottom plates



5) While compressing all the components, install the first screw from the bottom. Follow with the remaining screws (after installing the first screw, the remaining three will be easy to install).



**Please remember to use
Loctite Threadlocker
No. 242 Blue®
with the Phillips screws**



**Your standard flatfoot
is now installed.
Thank you!**

