Owl Inlay Kit Instructions

Kit components

1: 1 x Maple Barrel with laser cutout

2: 15 Color inlay pieces.

Step 1:

Remove all components from the plastic bag and place on a clean work surface. Please note that the components are small and you can loose them quite easily.

Step 2:

Take the barrel with the laser cutout and slide the brass tube(27/64) into it. Please do not use any glue at this stage, this is only to assist you with the assembly process.

Step 3:

Take the Barrel with cutout and place the inlays into the openings. There is no particular order to assemble the parts, just follow the numbers. You can use a little bit of water and wet the inlay before you press it in. Use masking tape to tape the pieces into place.

Apply a small amount of thin CA glue so it would stick to the main barrel. You can use CA accelerator to speed up the curing of the CA glue.

Step 5

Remove the brass tube and put a small drop of thin CA on each inserted part.

Step 6

Now you can trim / cut / sand the barrel to size and glue the brass tube into the barrel with a glue of your choice and please give it enough time to dry before turning the barrel into shape. Try to sand the barrel round and smooth before you use a skew or any other tool to finish your pen.

