- 1. Locate the studs in the wall and cut out an opening 21-1/4"H x 14-1/2"W at the desired installation height.
- 2. Remove the shelves and set them aside.
- 3. Place the safe into the wall opening and mark the (6) hole location on the studs. Drill into the studs at least 1-1/4" deep with a 3/32" diameter drill.
- 4. Install the safe into the wall using (6) $\#10 \times 1-1/2$ " long screws and (6) #10 washers (not supplied).
- 5. Reinstall the shelves.

