

Installing a V-Line Quick Vault



1. Check desired wall location for wiring and plumbing that could interfere
Locate and check spacing of studs
Mark studs



2. Measure desired height location



3. Draw out level lines to cut wall
14" wide x 12" high



4. Cut dry wall in between wall studs



5. Clean out opening of drywall dust



6. Install shelf at desired height, check to be sure it does not interfere with lock opening.



7. Slide Quick Vault into cut out



8. Pull back interior felt lining inside Quick Vault to locate installation holes, there are 2 on each side, on the hinge side the holes are toward the front, and are not threaded



9. Pre-drill holes into studs for screws
Fasten lag screws through Vault into stud, minimum recommended screw size $1/4" \times 1"$
Screw size may vary depending on location



10. Set your personal combination.

For complete concealment hang a picture over the Quick Vault