



TacticalWalls®

TACTICAL WALLS VMOD INSTRUCTIONS FOR FJ CRUISER MODELS

Congratulations on the purchase of your Tactical Walls VMod Package. Listen. We tried to make these instructions as simple as possible because lets face it, you drive a FJ Cruiser. If at any point in this process you feel intimidated or unsure of what to do. DO NOT attempt to zip tie, duct tape, or use bailing wire to install this product. If you are a Marine do not try to eat this product. Simply give us a call and we'll be happy to help you through the process.

Please visit us at tacticalwalls.com for more information, tips, tricks, and videos.

***THOROUGHLY READ ALL INFORMATION BEFORE ASSEMBLY.**

Your TacticalWalls VMOD Panel for your FJ requires that you drill holes to attach the VMod panel onto your rear door insert. If you are not comfortable or capable of modifying your door interior panel you may want to reconsider this purchase. If you laughed at that last sentence you are probably gonna love your VMod and get years of use out of it on the road and on the trail.

Step one:

Locate the two plugs at the top of your rear door interior panel and remove the plugs. You will have to pry them out with a small screwdriver.

Step two:

With the plugs removed use a socket to remove the hardware holding the panel onto the door.

Step three:

With the hardware removed. You will have to pop the rear insert off of the door. Starting in the top left corner gently pry the plastic insert away from the metal working your way down the panel as you go. Work across the bottom of the panel and then back up the right side until you reach the top right corner of the insert. Here is a helpful video showing this process. <https://www.youtube.com/watch?v=xO8SryBZ53A>

Step four:

With both sides and the bottom loose you can now lift the insert up and off of the metal door.

Step five:

Place the insert on a flat surface that you will be comfortable drilling on. Workbench and ground are good options. Kitchen counter, Coffee table, and waterbeds are BAD CHOICES.

Step six:

Lay your VMod panel onto your door insert lining the hardware holes that you removed the plugs from up with the C shaped features on the side of the VMod panel. It may be helpful to have a friend hold the panel steady while you mark and drill your first two holes. With the first two holes drilled use the supplied hardware to tighten the panel onto the insert and drill the remaining holes using the holes in the panel as your guide. Install the rest of the hardware and your panel will be permanently and securely attached to your door insert.

Step seven:

Reinstall your insert onto your door in the reverse order of the removal. Slide on from the top down. Snap into place around the perimeter. and install the two bolts and the plastic covers. You are now ready to install your accessories and enjoy your new storage and organization system.

Note: You can adjust the tension of your accessories by tightening the Allen screws that attach the accessories to the panel. This is especially important to keep the your gear secure when you are hitting the trail.

Thanks for your purchase and we hope you enjoy your VMod for years to come!