

LOGO SIDE OUT

NOTE: USE RTV Black Silicone Gasket maker. (Permatex or equivalent) between TTO-RSBD adapter plate and inside seal to Mopar Rubicon Sway Bar housing. This is your dust and water seal so ensure a good seal.

PULL OUT PISTON ENOUGH TO SCREW 1/4-28 NUT ONTO THREADED PISTON SHAFT. THIS ACTS AS A STOP AND A LOCK FOR ALUMINUM PART WHICH IS THREADED ON AFTER THE NUT IS ASSEMBLED.

