



## Colorado / Canyon Full Face Panel Instructions

### What's Included

- Full Face Panel
- Drillguide
- Screws and Washers
- Optional Voltmeter
- Optional Inverter Switch and Outlet

1. Start by removing all the included parts from the packaging, careful not to lose the small screws and washers.
2. Remove side trim pieces from the center console.
3. Remove OEM USB from cubby, these have tabs holding them in place.
4. Remove 12V plug, center of plug pushes out the front, then flip cover follows. These also have retaining tabs.
5. Place white drill-guide in cubby, mark drill points.
6. Drill out marked points with 3mm bit.
7. Drill as needed to run wiring behind panel.
8. Mount your switch panel to the full face panel.
9. Insert panel, attaching and running wires as you go.
10. Attach the 4 screws with washers into the threaded brass inserts of the panel.
11. Replace side trim pieces.

