



## JEEP JL DEAD PEDAL KIT INSTALLATION

Here's what's included in the kit. Install time is less than 30 minutes.

- Dead Pedal Bracket
- Mounting Plate
- Backing Plate with 10mm Locking Flange Nuts
- 10mm Welded Studs
- 13mm Tapered Bolt with Nyloc Nut



Open the driver's side door and find the metal reinforcement plate above the plastic kick panel.



Install the backing plate with the welded 1/4" bolts into the factory upper and lower holes in the metal plate utilizing the holes closest to the firewall.



Pick one of the 3 locations on the mounting plate and install the tabs of the dead pedal bracket into the mounting plate. Then, fasten the mounting plate to the dead pedal bracket by installing the 5/16" bolt into the countersunk hole in the backside of the mounting bracket and secure the bolt with flat washer. Lock washer and nut.



Install the assembled dead pedal over the 1/4" bolt from the backing plate and loosely install 1/4" flat washers, nuts on the bolts.



Test fit the dead pedal with your foot to make sure it is located where you want it to be. Make any necessary adjustments and once it is where you like it, tighten the nuts.