



**DUNLOP**  
KARTSPORT

# CARBON CAMERA MOUNT FITTING INSTRUCTIONS



**1**

Ensure you have a minimum of 12mm thread protruding from the nyloc nut on your seat bolt. If not replace the seat bolt with a longer bolt to achieve this. Remove nyloc nut and replace with serated nut as shown, making sure that the serated side faces away from the seat bar.



**2**

Screw carbon pole onto the seat bolt and firmly hand tighten against serated nut.



**3**

Fit the camera mount to the carbon pole along with the supplied rubber strip as shown, tighten in your desired position.

Available now in our online store or at the track...



**ALM**  
Sales Pty Ltd

**DUNLOP**

**DK**

**EVI4**  
dence

**DKAM**  
EVIDENCE 4

**mini me**  
HELMET STANDS

**GoPro**  
Be a HERO.

**RAM**  
MOUNTS  
WWW.RAMMOUNT.COM

**stilo**

**Red Bull**  
RACING  
**EYEWEAR**

Dunlop Kartsport's fantastic products, quality, service and the "piece of mind" in dealing with a trusted Australian company with over 30 years experience in Australian Karting is now only a CLICK away...

**ONLINE STORE** [www.dk17.com.au](http://www.dk17.com.au)