



CRUZ CAM SYNC INSTALL PROCEDURE



AIR GAP IS ALREADY SET AND LOCKED IN

Step 1: Remove old CAM sensor completely

Step 2: Get motor set on TDC (Top Dead Center)

Step 3: Rotate motor to required CAM sensor position on balancer

Step 4: Install CRUZ CAM Sync & be sure to align oil pump drive with hall effect sensor aiming towards radiator support. Rotate sensor clockwise until MSD hall effect sensor turns on. Once the hall effect sensor turns on, rotate the motor backwards just until hall effect sensor light goes out

Step 5: Lock down CAM Sensor as normal

