



CRUZ Performance E85 Rated Fuel Line Kit Install Procedure

- 1.** Put 45 ends from hoses on pump hanger.
- 2.** Run both lines across to driver side following factory feed lines
- 3.** Continue over rear end down to filter.
- 4.** Just in front of stock filter mine will go attach straight -8 Fitting
(Make sure to put arrow facing forward on the filter)
- 5.** Attach straight -8 to fuel filter and continue forward with both lines up frame rail to master cylinder.
- 6.** Cut across back of motor and come down valve cover/intake side.
- 7.** Straight -6 into regulator for return.
- 8.** -8 around the front of the motor to 45 into fuel rail

