

Microwave Pannier Upper Mounting Instructions

Thanks for choosing the Porcelain Rocket Microwave Panniers! Our novel laced Voilé Straps® mounting system will be unfamiliar at first, but we're confident that with a bit of practice, the lacing will quickly become intuitive. Please carefully follow these instructions; correct installation is required to ensure the longevity of the product, and a secure, rattle-free experience.

There are a multitude of options for lower mounting, using combinations of the five lower slots. The best solution for securing the bottom of the pannier will depend on your rack. Please visit <https://porcelainrocket.com/pages/microwave-pannier-examples> for several examples of lower mounting solutions.

Step one:

Start with the Voilé Straps® laced as shown, with the buckle pointed down, and the flat loop on the inside of the pannier:



Outside view



Inside View

Step Two:

Lace the tail of each Voilé Strap® around the bike rack rail, from bottom to top, then back through the same upper slot in the pannier backing plate. Then, lace the tail of the Voilé Straps® through the flat loops. Now is a good time to get everything snug, and under light tension. The flat loop takes the brunt of the tension, to protect the backing plate.



Step Three:

Bring the tail over the top of the backing plate, and close the buckle. You don't need to tension the Voilé Straps® much at this point. You should normally only need one or two holes exposed past the Voile buckle hook - any more than that will put unnecessary strain on the system.

