# PahaQue Wilderness, Inc T@B Trailer Tent SETUP INSTRUCTIONS



Thank you for purchasing the T@B Trailer Tent, another quality product built in the USA by PahaQue Custom Shop. This product is backed by our Limited Lifetime Warranty against any and all defects in materials and workmanship. When used and cared for properly, this product will provide many years of reliable service.

### A FEW QUICK NOTES:

- **SET-UP**---Your Tent can be easily set-up in 10 minutes or less by one or two people, if you follow the basic sequence detailed below. If time allows, we would recommend that you read through these instructions in their entirety and do a practice set-up at home before heading into the wilderness. Then you can be sure all components are present & functional, and proceed through the set-up sequence at a leisurely pace to learn the most efficient techniques.
- **TAKE DOWN** --- For the take down, simply reverse the set-up sequence.
- LONG TERM STORAGE --- Your T@B Trailer Tent is more likely to be damaged by mold, mildew or bacteria during storage than by elements while set up and in use. Make sure that all food or other organic material is removed, and that your tent is thoroughly dry before packing into the stuff bag. If you have to pack up and leave the campsite while your tent is damp, set it up later at home & allow it to dry thoroughly for long-term storage.

## How to install your T@B Trailer Tent by PahaQue

- 1. Locate the following parts included with your T@B Trailer Tent:
  - Tent
  - Trailer Skirt
  - One fiberglass pole
  - One Aluminum roof pole
  - Ground stakes 6
  - Rear adjustment flap
- 2. **Locate** the trailer skirt. Starting at the ends of the bottom keder rail closest to the trailer door, insert the right half, and then the left (rear) half of the skirt into the position. See Photo A
- 3. **Unfold** Tent and locate keder cord edge of Tent. See Photo B.



- 4. **Starting** at the rear of the trailer, slide the Tent keder cord into the keder rail on the passenger side of your trailer. Make sure that the keder cord is able to feed freely into the rail as you pull the Tent towards the front of the trailer. The keder cord should fit completely into the rail, with little or no excess hanging out on either end.
- 5. **Locate** and assemble the aluminum roof pole. At the top-dead-center of the Tent in the front and on the keder edge against the trailer are roof pole pockets. Insert both ends of the roof pole into the pole pockets.
- 6. Locate the pole sleeve (black fabric) on the outer edge of the Tent. Carefully insert the fiberglass pole into the pole sleeve, until there is approximately 18"
- 7. **Starting** at one end, insert the pole tip into the grommet on the webbing at the lower corner of the Tent, as shown in Photo D.

extended from each end of the sleeve. See Photo C.

- 8. **Proceed** to the opposite end of the pole sleeve, and repeat the procedure with the pole tip at that end. In order to complete this step, you will have to bend the pole and create the curved shape of the Tent.
- 9. **Pull** the Tent out and away from the trailer. Using two ground stakes (one on either side) and the two adjustable webbing guylines located at the front of the Tent on either side, secure the Tent in place, and adjust the webbing straps as needed to get a tight pitch of the Tent. To tighten the roof material, a guyline should be extended out from the webbing strap located above the door.
- 10. **Stake** the 4 corners of the Tent down using the remaining ground stakes. If you desire to roll up the side panels, then those corners will not be staked. However the front two corners should always be staked to the ground to ensure stability and proper performance of the Tent.





## **USEFUL TIPS:**

- If you have difficulty sliding the keder cord through the rail, a little dish soap will help without damaging the Tent.
- While taking care not to over-tighten the adjustable webbing straps, it is important to not allow the Tent to sag where water could collect during a rain storm.
- Do not store your Tent while wet for any extended period; always dry completely prior to long-term storage.

You can register your product online by visiting www.pahaque.com, or by calling us toll-free at 1.888.700.TENT (8368).

\*Note the included rear adjustment flap (pictured below). Because of different trailer models and trim packages, the gap at the rear of the trailer between the skirt and the tent body itself will differ from trailer to trailer. The rear adjustment flap can be positioned as needed to fill this gap.



#### !CAUTION!

The effects of wind and rain on the Tent are unpredictable. Damage to the trailer and/or Tent may result. Please remove the Tent in heavy wind or rain. Damage due to weather is not covered by your warranty.