


# Sit to Stand Single Monitor Desk Mount Workstation Instruction Manual



# SKU: STAND-SIT1B



Scan the QR code with your mobile device or follow the link for helpful videos and specifications related to this product.

https://vivo-us.com/products/stand-sit1b

GET IN TOUCH | Monday-Friday from 7:00am-7:00pm CST







help@vivo-us.com

www.vivo-us.com Chat live with an agent! 309-278-5303


# NARNING!

If you do not understand these directions, or if you have any doubts about the safety of the installation, please call a qualified technician. Check carefully to make sure there are no missing or defective parts. Improper installation may cause damage or serious injury. Do not use this product for any purpose that is not explicitly specified in this manual. Do not exceed weight capacity. We cannot be liable for damage or injury caused by improper mounting, incorrect assembly or inappropriate use.



## WARNING: CHOKING HAZARD

SMALL PARTS - NOT FOR CHILDREN UNDER 3 YEARS. ADULT SUPERVISION IS REQUIRED.



NOTE: NOT ALL HARDWARE INCLUDED WILL BE USED

## TOOLS NEEDED




#### DO NOT EXCEED WEIGHT CAPACITY.

Failure to do so may result in serious injury.



# **ASSEMBLY STEPS**


# STEP 1



#### STEP 2


### **OPTION A: Clamp Installation**

Attach five rubber pads **(K)** to clamp **(B)**. Secure pole **(M)** to clamp **(B)** by tightening grub screw in the clamp using 3mm Allen key **(P)**. Secure clamp to the desktop.




#### **OPTION B: Grommet Installation**

If you are securing the stand to the desktop without clamp (**B**), use existing grommet hole, or drill a %" (10mm) hole. Attach base (**C**) to pole (**M**). Tighten grub screws in base (**C**) using 3mm Allen key (**P**). Attach five rubber pads (**K**) to the bottom of base (**C**). Remove screw from top of bolt in clamp (**B**) using Phillips screwdriver. Remove hand bolt from clamp and use with Support Plate (**D**) to attach pole (**M**) to desk as shown in diagram.




#### STEP 3


Slide cable management clips (J) and both keyboard arm (A) and monitor arm (G) over top of pole (M) as shown in diagram. Secure both arms using 6mm Allen key (Q). Attach keyboard tray (H) to arm (A) using four bolts (O) and four nuts (N). Tighten using wrench (R) and Phillips screwdriver. Place pad (I) on left or right side of keyboard tray (H).




## STEP 4




# STEP 5





# STEP 7





## Open Monday - Friday 7:00am - 7:00pm CST,

our dedicated support team can offer immediate assistance with rapid response times. If any parts are received damaged or defective, please contact us. We are happy to replace parts to ensure you have a fully functioning product.

 $\subseteq$ 

help@vivo-us.com

AVG. RESPONSE TIME (within office hrs): 1HR 8M

- 23% within < 15m
- 38% within < 30m
- 61% within < 1hr
- 83% within < 2hr
- 92% within < 3hr



www.vivo-us.com
Chat live with an agent!

AVG. RESOLUTION TIME (within office hrs): < 15 M



309-278-5303

AVG. RESOLUTION TIME (within office hrs): 5M 4S